

HOW TO LAY LINK EDGE

USING LINK EDGE WILL GIVE YOU A HIGH CLASS FINISH TO YOUR GARDEN AREAS

INSTRUCTIONS

- 1. Clear the area, compact and level the base surface.
- 2. Place a length of Link Edge on the surface in the desired shape and position.
- 3. Starting at one end, half-hammer spikes into the pre-punctured holes in the Link Edge. Ensure the edge spikes are only half inserted into the surface.
- 4. Four spikes are recommended for every three metre length, however, more may be required in pivotal areas and at points where a bend or curve is desired.
- 5. If any additional lengths are required, slide a fishplate connector into the second Link Edge length.
- 6. Snap the second length to the fishplate connector to create a smooth, uninterrupted edge.
- 7. Ensure the position of the Link Edge is correct. If it needs to be repositioned, remove the edge spikes that had been half-hammered into the base surface and later the position.
- 8. Once satisfied with the position, firmly hammer the spikes into the ground.

CHECKLIST

- ☐ Link Edge 3mm lengths
- ☐ Fishplate connections
- ☐ Fishplate corners
- ☐ Edge Spikes (4 spikes for every length or more for curves)
- Personal Protection Equipment (e.g. gloves)
- ☐ Straight edge or rake for leveling ground Hammer

